RADIOACTIVIDAD NATURAL EN AGUAS DE **CONSUMO HUMANO**

NATURAL RADIOACTIVITY IN WATER FOR HUMAN CONSUMPTION

SEMINARIO ONI

ALCHEMIA

LIFE ALCHEMIA



RESULTS OF THE LIFE ALCHEMIA PROJECT Radionuclide removal in the HMO pilot plant in Viimsi, Estonia

Siiri Salupere, PhD

researcher in radiation protection

Institute of Physics, University of Tartu

Estonia

17.06.2021

tection y of Tartu



OUTLINE

- How does HMO work for radionuclide removal?
- What does it mean for a water treatment plant operator?
- Regulatory requirements in Estonia
- Results:
 - Radium removal efficiency
 - Radionuclides in filter backwash water
 - Radionuclides in filter material



Tallinn

Pärnu



RADIONUCLIDE REMOVAL WITH THE HMO-TECHNOLOGY. HOW DOES IT WORK?

HMO =hydrous manganese oxide

Radium removal*:

- Sorption on MnO₂
- Sorption on hydrous oxides
 - Fe(OH)₃
 - Mn(OH)₄

*Also works for other bivalent metal cations.



Fig.: Goi et al., 2019. Journal of Water Process Engineering 30 (2019) 100464



RADIONUCLIDE REMOVAL WITH THE HMO-TECHNOLOGY. WHAT DOES IT MEAN?



water quality standards



the filter material

- NORM waste management





REGULATORY REQUIREMENTS FOR RADIOLOGICAL PARAMETERS

Drinking water

Parametric values given by EU Directive 2013/51/Euratom.

Limit values given by EU Directive 2013/59/Euratom.

Indicative dose (ID)	≤ 0.10 mSv/year	Exemption
Tritium (³ H) activity concentration	≤ 100 Bq/L	^{_226} Ra:
Radon (²²² Rn) activity concentration	≤ 100 Bq/L	²²⁸ Ra, ²²

$$ID = \sum A_i \cdot f_i \cdot V$$

Committed effective dose from all the radionuclides* in water.

*Excluding tritium, potassium-40, radon and short-lived radon decay products.

 \mathbf{A}_i – Activity concentration of radionuclide in water (Bq/L)

 f_i – Effective dose coefficient of the radionuclide (Sv/Bq)

V – Yearly water consumption (2 L per day = 730 L per year)

Filter material

levels

²³⁸U decay series

²⁸Th: ²³²Th decay series

Dose criteria for NORM

1000 Bq/kg

1000 Bq/kg

1 mSv/year

Our aim with the HMO pilot plant: **OPTIMIZED TREATMENT** Remove as much radium as needed to

guarantee ID < 0.10 mSv/year.

Not as much radium as possible!

Reduce NORM accumulation.



RESULTS: RADIUM REMOVAL EFFICIENCY FROM WATER



10.03.20



RESULTS: RADIONUCLIDES IN FILTER BACKWASH WATER



- material.
- Backwash water is discharged directly to the sewerage.

10.03.20 18.06.20





RESULTS: RADIONUCLIDES IN FILTER MATERIALS

- Radionuclides accumulate more on the upper part of the filter.
- **Exemption** levels exceeded in anthracite \rightarrow NORM waste.
- **Exemption** levels are not exceeded in sand \rightarrow regular waste.







CONCLUSIONS

HMO technology for drinking water treatment:

- Continuous dosing (HMO dose rate 0.15 L/h) ensures radium removal efficiency 80-90%.
- Significantly lower NORM waste generation rate than the current technology in Viimsi.
- Stable performance when the technology is operated continuously.

THANK YOU FOR YOUR ATTENTION! Any questions?

The study is performed in the framework of the LIFE ALCHEMIA project – LIFE16 ENV/ES/000437 (www.lifealchemia.eu) – which is financially supported by the LIFE Programme of the European Union. The presentation reflects only the views of the authors. The European Commission/Agency is not responsible for any use that may be made of the information it contains.

dium removal efficiency 80-90%. e current technology in Viimsi. ntinuously.